




# Water Fill Station

## Operation Instructions

Step 1: Using the keypad, type your Access Code and then press **ENTER**



Step 2: Enter the associated PIN # and press **ENTER**



Step 3: Enter the desired volume of water in gallons and press **ENTER**



Step 4: Is fill hose connected? If YES press **START** to begin filling.



Step 5: Users may pause water flow (120 second max) by pressing **FP** or press **STOP** to stop filling.



Step 6: System working will display the volume dispensed and will return to the ready display when fill is complete.

